




















Pantum BP5100/BM5100 Series Spare Part List

Version: 20211123

Printer Explosion Map









Note: FYI only, all subject to Actual

No. (Same as above picture numbers.)	Name of Unit	Spare Part Name (Chinese)	Spare Part Name (English)	SAP Part Number	Used for model ("*" represents any numbers)		Photo	Minimun Order (Piece/box)	Net Weight(g)
1	Data Board	数据基板	Data board	302110010501	BM5100FDN			1	81.0
		数据基板	Data board	302110010601	BM5100FDW				
		数据基板	Data board	302110004301	BP5100DW				
		数据基板	Data board	302110004401	BM5100ADW				
		数据基板	Data Board	30211016401	BP5100DN				
		数据基板	Data board	302110010401	BM5100ADN				
		电源板与数据基板连接线	Power-Engineboard wiring harness	301022265001	BP5100DN/BP5100DW/BM5100ADN/BM5100ADW/BM5100FDN/BM5100FDW			9	6.1
2	Laser Unit	激光器 (自制)	LSU	301022764001	BP5100DN/BP5100DW/BM5100ADN/BM5100ADW/BM5100FDN/BM5100FDW			1	299.3
		自制激光器线束(5束)	LSU wire(5bundles)	301022766001	BP5100DN/BP5100DW/BM5100ADN/BM5100ADW/BM5100FDN/BM5100FDW			9	2.8
		自制激光器线束(12束)	LSU wire(12bundles)	301022765001	BP5100DN/BP5100DW/BM5100ADN/BM5100ADW/BM5100FDN/BM5100FDW			9	12.0
		激光器组件 (自制)	LSU(with cable)	302110024701	BP5100DN/BP5100DW/BM5100ADN/BM5100ADW/BM5100FDN/BM5100FDW			1	315.0
3	Fuser Unit	定影组件 - 220V	Fuser Unit - 220V	302111018801	BP5100DN/BP5100DW/BM5100ADN/BM5100ADW/BM5100FDN/BM5100FDW			1	813.0
		定影驱动大齿轮	Fusing driver gear	301022312001	BP5100DN/BP5100DW/BM5100ADN/BM5100ADW/BM5100FDN/BM5100FDW			9	11.9
4	Power Board Unit	电源基板	Power Board	302111016101	BP5100DN/BP5100DW/BM5100ADN/BM5100ADW/BM5100FDN/BM5100FDW			1	269.5
5	Engine Board Unit	引擎基板	Engine Board	302111016201	BP5100DN/BP5100DW/BM5100ADN/BM5100ADW/BM5100FDN/BM5100FDW			1	83.0
		引擎板与主马达连接线束	Chip contact wiring harness(Toner)	301022282001	BP5100DN/BP5100DW/BM5100ADN/BM5100ADW/BM5100FDN/BM5100FDW			9	36.0
		引擎与数据基板线束	Chip contact wiring harness(Drum)	301022283001	BP5100DN/BP5100DW/BM5100ADN/BM5100ADW/BM5100FDN/BM5100FDW			9	1.6
		引擎与数据基板排线	Engine Board Cable	302111017601	BP5100DN/BP5100DW/BM5100ADN/BM5100ADW/BM5100FDN/BM5100FDW			9	1.8
6	ADF Unit	ADF扫描头	Adf Cis	301022681001	BM5100ADN/BM5100ADW/BM5100FDN/BM5100FDW			4	46.3
		ADF搓纸辊	Adf pick-Up assembly	301022302001	BM5100ADN/BM5100ADW/BM5100FDN/BM5100FDW			9	27.0
		ADF开关传感器	Adf switch sensor	301022300001	BM5100ADN/BM5100ADW/BM5100FDN/BM5100FDW			9	2.5
		ADF马达	Adf motor	301022301001	BM5100ADN/BM5100ADW/BM5100FDN/BM5100FDW			8	50.0
		ADF分离组件	Adf Separator Assembly	301022149001	BM5100ADN/BM5100ADW/BM5100FDN/BM5100FDW			9	10.9

		ADF先端感应基板	Paper feed sensor	301022294001	BM5100ADN/BM5100ADW/BM5100FDN/BM5100FDW		9	1.4
		稿台支架 (浅灰)	Scan Support Rod(Grey)	301022324001	BM5100ADN/BM5100ADW/BM5100FDN/BM5100FDW		8	8.0
7	Scanner Component	扫描仪压盖(灰白)	Scan Gland (White old)	301022838001	BM5100ADN/BM5100ADW/BM5100FDN/BM5100FDW		1	/
		扫描马达	Scan Motor	301020094001	BM5100ADN/BM5100ADW/BM5100FDN/BM5100FDW		9	36.0
		扫描头	Cis	301022812001	BM5100ADN/BM5100ADW/BM5100FDN/BM5100FDW		4	4.0
		扫描皮带	Scan belt	301022303001	BM5100ADN/BM5100ADW/BM5100FDN/BM5100FDW		9	1.1
		扫描头排线	Scan head flatcable	301022285001	BM5100ADN/BM5100ADW/BM5100FDN/BM5100FDW		9	3.8
		扫描左侧从动轮	Scanner Cover Clutch	302110036001	BM5100ADN/BM5100ADW/BM5100FDN/BM5100FDW		9	1.6
		扫描复位传感器	Scan reset sensor	301022184001	BM5100ADN/BM5100ADW/BM5100FDN/BM5100FDW		9	3.5
		扫描仪右侧被动轮组	Scan driven wheel unit	301022325001	BM5100ADN/BM5100ADW/BM5100FDN/BM5100FDW		9	4.8
9	Duplex Unit	双面打组件 (灰白)	Duplex unit (Grey)	301022233001	BP5100DN/BP5100DW/BM5100ADN/BM5100ADW/BM5100FDN/BM5100FDW		1	218.3
10	Paper Supply Unit	纸盒组件 (灰白)	Paper Tray Assy	302111016901	BP5100DN/BP5100DW/BM5100ADN/BM5100ADW/BM5100FDN/BM5100FDW		1	688.5
		进纸托盘外壳	Automatic Paper Feed Tray Lid (Outside Lid)	302111017501	BP5100DN/BP5100DW/BM5100ADN/BM5100ADW/BM5100FDN/BM5100FDW		1	89.5
		多功能纸盒驱动组件	Multi Paper Tray Driver Assy	302111011601	BP5100DN/BP5100DW/BM5100ADN/BM5100ADW/BM5100FDN/BM5100FDW		8	8.0
		多功能纸盒纸有无连接线	Multi Paper Tray Sensor Cable	302111006801	BP5100DN/BP5100DW/BM5100ADN/BM5100ADW/BM5100FDN/BM5100FDW		9	1.5
11	Control Panel Unit	控制面板 (带LCD屏)	Control panel board	302111016601	BP5100DN/BP5100DW		4	4.0
		控制面板排线C	Control panel flat cable(3In1)	301022273001	BM5100ADN/BM5100ADW		9	4.0
		控制面板排线(LCD)A	Control panel flatcable(Lcd)-A	301022271001	BP5100DN/BP5100DW		9	2.7
		显示屏	Lcd screen-S	301022318001	BP5100DN/BP5100DW/P3010DW/P3300DN P3300DW		9	8.7
		显示屏	Lcd screen-S	301022319001	BM5100ADN/BM5100ADW/BM5100FDN/BM5100FDW		9	9.0
12	Upper Cover	扫描仪上盖组件(灰白)	Glass platen component (Grey)	301022811001	BM5100ADW/BM5100FDN/BM5100FDW/BM5100ADN		1	837.0
		上盖 (灰白)	Top Cover (White)	302111017701	BP5100DN/BP5100DW		1	837.0
		上盖 (灰白)	Top Cover (White)	302111017801	BM5100ADN/BM5100ADW/BM5100FDN/BM5100FDW		1	837.0
13	Left Cover	左盖 (灰白)	Left Cover (White)	302111018101	BP5100DN/BP5100DW		1	289.0
		左盖 (灰白)	Left Cover (White)	302111018201	BM5100ADN/BM5100ADW/BM5100FDN/BM5100FDW		1	289.0
14	Right Cover	右盖 (灰白)	Right Cover (White)	302111018301	BP5100DN/BP5100DW/BM5100ADN/BM5100ADW/BM5100FDN/BM5100FDW		1	233.0
	Rear Cover	后盖组件 (灰白)	Rear Cover (White)	302111017901	BP5100DN/BP5100DW/BM5100ADN/BM5100ADW/BM5100FDN/BM5100FDW		1	159.0
15	Paper Exit Unit	排出框架 (中灰色)	Discharge Frame (Medium ash)	302111017001	BP5100DN/BP5100DW/BM5100ADN/BM5100ADW/BM5100FDN/BM5100FDW		1	106.0
		排出感应基板连接线	Switch wiring harness-D2	301022270001	BP5100DN/BP5100DW/BM5100ADN/BM5100ADW/BM5100FDN/BM5100FDW		9	2.5
		排纸感应器线束	Paper exit sensor wiring harness	301022281001	BP5100DN/BP5100DW/BM5100ADN/BM5100ADW/BM5100FDN/BM5100FDW		9	2.8

		排纸感应器组件	Paper exit sensor	301022231001	BP5100DN/BP5100DW/BM5100ADN/ BM5100ADW/BM5100FDN/BM5100F DW		9	3.2
16	Cartridge Unit	芯片触点基板 (粉盒)	Chip contact board(Toner)	301022298001	BP5100DN/BP5100DW/BM5100ADN/ BM5100ADW/BM5100FDN/BM5100F DW		9	4.5
		芯片触点基板 (鼓)	Chip contact board(Drum)	301022299001	BP5100DN/BP5100DW/BM5100ADN/ BM5100ADW/BM5100FDN/BM5100F DW		9	1.8
17	Fan Unit	风扇	Fan	302111016001	BP5100DN/BP5100DW/BM5100ADN/ BM5100ADW/BM5100FDN/BM5100F DW		9	63.0
18	Other Units	搓纸轮	Pick-Up Roller	301022176001	BP5100DN/BP5100DW/BM5100ADN/ BM5100ADW/BM5100FDN/BM5100F DW		9	10.5
		马达	Motor	301022163001	BP5100DN/BP5100DW/BM5100ADN/ BM5100ADW/BM5100FDN/BM5100F DW		8	8.0
		输稿器分离片	Vice-Separator Pad	301022150001	BP5100DN/BP5100DW/BM5100ADN/ BM5100ADW/BM5100FDN/BM5100F DW		90	1.8
		双缺齿组件	Pick-Up assembly	301022321001	BP5100DN/BP5100DW/BM5100ADN/ BM5100ADW/BM5100FDN/BM5100F DW		9	12.7
		硒鼓驱动大齿轮	Drum driver gear	301022313001	BP5100DN/BP5100DW/BM5100ADN/ BM5100ADW/BM5100FDN/BM5100F DW		9	8.4
		先端感应基板线束	Paper feed sensor wiring harness	301022284001	BM5100ADN/ BM5100ADW/BM5100FDN/BM5100F DW		9	1.1
		先端感应臂	Paper feed flag	301022304001	BM5100ADN/ BM5100ADW/BM5100FDN/BM5100F DW		9	0.7
		转印辊轴承	Transfer roller bearing	301022317001	BP5100DN/BP5100DW/BM5100ADN/ BM5100ADW/BM5100FDN/BM5100F DW		9	1.0
		给纸电磁铁	Electro magnet	301020147001	BP5100DN/BP5100DW/BM5100ADN/ BM5100ADW/BM5100FDN/BM5100F DW		9	26.8
		转印辊	Transfer Roller	302111017101	BP5100DN/BP5100DW/BM5100ADN/ BM5100ADW/BM5100FDN/BM5100F DW		12	12.0
		纸满传感器组件	Paper-Full Sensor	302111016701	BP5100DN/BP5100DW/BM5100ADN/ BM5100ADW/BM5100FDN/BM5100F DW		9	24.5
		搬送进纸传感器组件	Transfer Paper Input Sensor	302111007001	BP5100DN/BP5100DW/BM5100ADN/ BM5100ADW/BM5100FDN/BM5100F DW		9	5.7
		纸有无传感器组件	Paper sensor	302111006901	BP5100DN/BP5100DW/BM5100ADN/ BM5100ADW/BM5100FDN/BM5100F DW		9	3.5
		马达连接线	Motor Cable	301022330001	BP5100DN/BP5100DW/BM5100ADN/ BM5100ADW/BM5100FDN/BM5100F DW		9	9.0
		纸有无连接线	Paper Sensor Cable	302111006701	BP5100DN/BP5100DW/BM5100ADN/ BM5100ADW/BM5100FDN/BM5100F DW		9	3.3
		齿轮离合器连接线	Clutch Cable	302111017301	BP5100DN/BP5100DW/BM5100ADN/ BM5100ADW/ BM5100FDN/BM5100FDW		9	3.3
		粉盒搬送oneway齿轮	Oneway Gear	301022735001	BP5100DN/BP5100DW/BM5100ADN/ BM5100ADW/BM5100FDN/BM5100F DW		9	10.8
		双面打oneway齿轮	Duplex Unit Oneway	301022736001	BP5100DN/BP5100DW/BM5100ADN/ BM5100ADW/BM5100FDN/BM5100F DW		9	5.4
		纸有无感应基板	Paper sensor	301022293001	BM5100ADN/ BM5100ADW/BM5100FDN/BM5100F DW		9	0.7
		纸有无感应臂	Paper empty flag	301022292001	BM5100ADN/ BM5100ADW/BM5100FDN/BM5100F DW		9	0.7
		齿轮离合器	Clutch	302111017201	BP5100DN/BP5100DW/BM5100ADN/ BM5100ADW/ BM5100FDN/BM5100FDW		9	13.5
		搓纸轮	Pick-Upassembly	301022230001	BP5100DN/BP5100DW/BM5100ADN/ BM5100ADW/BM5100FDN/BM5100F DW		9	9.6
		导电触点	High voltage contact	301022297001	BP5100DN/BP5100DW/BM5100ADN/ BM5100ADW/BM5100FDN/BM5100F DW		45	2.2
		分离辊组件	Separator roller	301022320001	BP5100DN/BP5100DW/BM5100ADN/ BM5100ADW/BM5100FDN/BM5100F DW/		9	11.5
		搬送传感臂	Transfer sensor flag	301022296001	BP5100DN/BP5100DW/BM5100ADN/ BM5100ADW/BM5100FDN/BM5100F DW		9	1.3
		搬送感应基板	Transfer sensor	301022295001	BP5100DN/BP5100DW/BM5100ADN/ BM5100ADW/BM5100FDN/BM5100F DW		9	2.8

		搬送感应器线束	Transfer sensor wiring harness	301022280001	BP5100DN/BP5100DW/BM5100ADN/BM5100ADW/BM5100FDN/BM5100FDW			9	1.6
		电磁铁线束	Solenoid wiring harness	301022279001	BP5100DN/BP5100DW/BM5100ADN/BM5100ADW/BM5100FDN/BM5100FDW			9	2.4
		马达线束	Motor wiring harness	301022268001	BP5100DN/BP5100DW/BM5100ADN/BM5100ADW/BM5100FDN/BM5100FDW			9	5.9
19	Platen Component	扫描仪上盖组件(灰白)	GlassPlatenComponent(grey)-NEW	302110017901	BM5100ADN/BM5100ADW/BM5100FDN/BM5100FDW			1	837
		扫描仪压盖(灰白)	Scan Flat Plate (Light grey) -NEW	302111026001	BM5100ADN/BM5100ADW/BM5100FDN/BM5100FDW			1	430
		扫描组件 (带ADF 灰白)	Scanner assembly(With ADF)	302110031201	BM5100 Series			1	1200